



User Manual I785D8DCZ



EMPIRE



User Manual

Thank you for purchasing EMPIRE Intel Tablet Model I785D8DCZ. This user manual introduces every function of the TABLET briefly, which let you have an easy control in it and enjoy its value fully. Please read this manual carefully before use.

Announcements

1. Please note that the new battery is only able to achieve the best performance after two or three charge and discharge cycles completely.
2. For the first three times charge battery, please make sure the charging time should be 8-10 hours at least. After it, the battery can be full charged about 4 cycles.

These make lithium battery achieved its best performance in the future.

3. To prevent data loss, it is recommended that users should back up important data, especially before the firmware upgrade. We are not be responsible for any losses caused by data loss.
4. This machine is a high-precision electronic product, please do not disassemble by yourself.
5. Please avoid any strong beat or collide the device.
6. Avoid using the device in the following environments: high temperature, low temperature, humid, dusty, powerful magnetic field and long-term exposure under sunlight.
7. It's allow to wipe the device's casing gently by wet cloth drying, and any other chemical

solution cleaning is strictly prohibited.

8. The device cannot be suffered any drip and splash, and it should not be placed near something like cups filled liquid.
9. To avoid hearing damage, please choose the appropriate volume while listening.
10. Do not alter any part of the device.
11. Please only use the batteries, chargers and accessories manufacturers allowed. It will be violate the warranty regulations or may be dangerous if you use any other ones
12. Please follow the relevant local environmental regulations to dispose the discarded

Device and accessories.

13. If there is any questions during using, please contact the local dealer or our company's Customer service center directly.
14. All specifications or others are subject to change without notice.

Manual Catalogue:

Product specifications

Appearance and Key Description

Operation keys introduction

- Getting Started

Below are the common things which need to know about the device for operating first time.

The use of functions

1. WIFI
2. 3G
3. Bluetooth
4. Play Music
5. Play video
6. Picture browsing
7. Photograph

8. Recording
9. G-SENSOR
10. Download and Use Application

Charging Step

1. Charge the unit via MIC-USB adapter.


Abnormal restart

Frequently Asked Questions

Product specifications

- Model: TM-MID785i
- FLASH Capacity: 8GB
- DDR Capacity: 1GB
- USB port: micro USB
- Display: 7.85 inch (type); 1024 × 768
(Display pixels)
- Battery: Rechargeable polymer lithium ion
battery
- Size: 200mm (L) * 137mm (W) * 7.2mm (H)

Appearance and Key Description:



Operation keys introduction:

1. Reset button: Press the power button to force shutdown 10s
2. Power: Long press to open the device, short press to wake up the device while standby, long press to off the device.
3. Volume + / - : Short press to adjust the volume.

Getting Started

Boot device

According to "Power" button in the

Appearance and Keys description, long press it to turn on the device.


Transfer data

Connect the device with computer PC through the USB cable in package, a PC with a computer connection (to open USB data connection), the need to transfer music / video / file copy in the computer's hard drive, switch to the TABLET disk paste can achieve data transfer.

The use of functions:


1. WIFI

Turn on the WIFI in "Settings" menu, click search, select the available network and connect it via enter the correct password.



2. 3G


Connect an external 3G (WCDMA) or GSM card in device, pop-up settings menu, turn on the mobile network (which default turn on) and wait for the 3G network connect. You can use the mobile Internet once the signal icon appears on the lower right corner.



3. Bluetooth

Turn on Bluetooth in “Settings”. The unit will search for Bluetooth devices automatically, then you can select a device pairing. Once the pairing


is succeed finished, you can transmit / receive files



4. Music


Simply click the "Music" into the music player interface, you can download different styles of Music players according to your preference. The

unit can support music format of MP3, wav, aac or ogg.




5. Video

Simply click the "Video Player" for playing, you can download different styles of Video players according to your preference. The unit can support video format of 3gp, webm, mov or MP4.




6. Picture

You can browsing the picture by click into the “Gallery”, and also can set the picture as the desktop background.




7. 2 Megapixel / 5 Mega Pixel camera

Click the “Camera” in menu, you can select photos or use the camera function. Insert the TF card into unit, the photos can be saved in it.




8. Recording

Click the "Record" menu directly for enter the recording interface.



9. G-SENSOR

G-SENSOR can be turned on or off from the "Display" in the "Settings", and auxiliary functions in the lower right corner of the menu or "settings".



10. Download and Use Application

Method 1: Copy APK from the computer to the device then installed.

1. Copy the application which with suffix ". apk" from computer to device or TF Card.
2. In Settings - security, open "Unknown source", then open the file manager to find the corresponding APK.

3. Click the APK will need to install, then there is one prompt dialog box shows "Install" "Cancel". Click "Install " and waiting for installing APK. After finish, it will shows "Application is already installed". Click "Finish" to continue to install other or click "Open" to open the current installed application directly.

Method 2: The application installation method downloaded from Network

1. Install and download ". Apk " market applications through "APK installer". For example, Google Market, etc.

2. Open the page, you can find a large number of sorted applications. Click on any application, there will be shows the option of "Install", then click "Install", it will prompt

"Downloading ----> Finished download ----> Download is finished and is being installed ----> Install succeed". At this time, you can open this application or click" Uninstall " to uninstall it.

3. You can also download the application by any web page directly.

Note: The applications which downloaded from Website just can be saved in TF card.

There is many Website for Download apk application, you can search them in the Website directly.

Charging Step

1. Using adapter for charging

Special note: The adapter's specification must be accord with the following requirement. Any accident or failure based on not accord with the adapter requirement, we regard it as man-made damage.

Name: Adapter

Input: AC100V~240Hz ,50Hz/60Hz

Output: DC5.0~2000MA

Interface Standard: USB MICRO standard interface

Abnormal restart:

If there is anomalies caused by illegal operation, such as fixed screen, can not operate etc., all can be got right after reset it through the "RESET" which in the side of the device and then turn on device again.

Frequently Asked Questions

① The players can not boot

- Check battery with power or not
- Connect the adapter and check again
- If it still can not boot after charging, please contact our customer service.

② The earphone can not hear sound

- Check the volume is set to 0 or not.
- Check the earphone connection is OK or not

③ Button does not work

- Please confirm whether the electronic lock is locked or not. If locked, try again after slipping upward lock or power button to unlock.

④ Serious noise

- Check the earphone plug is clean or not, dirt can cause noise.
- Check the music file is damaged or not. Try to confirm it by playing other music. If the file has

been damaged, it may cause very serious noise or skips.

⑤ The screen garbled

- Check that you have set the correct language or not. You can find and set it in < Settings> -- <System settings> -- <Language selection>.

⑥ Can not download files

- Make sure the computer and player is properly connected
- Check the storage space of memory is full or not
- Check the USB cable is damaged or not



EMPIRE